

Fermi National Accelerator Laboratory Batavia, IL 60510

FERMI MAIN INJECTOR

3Q60 COIL ASSEMBLY/INSULATION TRAVELER

Reference Drawing(s)

3Q60 Half-Coil Assembly MD-331984 3Q60 Complete Coil Assembly MD-331966

Budget Code: MY1	Project Code: CII	
Released by:	Date:	
Prepared by: W. L. Isiminger		
Title	Signature	Date
TD / E&F Process Engineering	Gob This	7/0/28
TD / E&F Assembly	Sant hus	7/13/98
TD / E&F Tooling	Marson	1/13/28
TD / E&F Fabrication Manager	Elanon	7/13/98
TD / E&F Device Design	Melandeltrist	7/13/27
TD / E&F Department Head	Varas	7/14/92
TD / QA/QC Manager	MN. Stol	7-15/98
TD / Main Injector Magnet Project Manager	Watt Dayling	7/13/98
BD / Main Injector Magnet Liaison Project Physicist	Wands March	7/13/98

Specification # 5520-TR-333291 July 9, 1998 Rev. A

Revision Page

Revision	Revision Description	Date
Á	Step 3.7: Added Ls and Q limits for 100 Hz measurements per unreleased specification ES-331810 Rev. D received from D. Gaw.	07/09/98
	TRR No. 0860	

FMI 3Q60 Coil Assembly/Insulation

3

Ensure appropriate memos and specific instructions are placed with the traveler before issuing the sub traveler binder to production.

1.0 General Notes

- White (Lint-Free) Gloves (Fermi stock 2250-1800) or Surgical Latex Gloves (Fermi stock 2250-2494) shall be worn by all personnel when handling all product parts after the parts have been prepared/cleaned.
- 1.2 All steps that require a sign-off shall include the Technician/Inspectors first initial and full last name.
- 1.3 No erasures or white out will be permitted to any documentation. All incorrectly entered data shall be corrected by placing a single line through the error, initial and date the error before adding the correct data.
- 1.4 All Discrepancy Reports issued shall be recorded in the left margin next to the applicable step.
- 1.5 All personnel performing steps in this traveler must have documented training for this traveler and associated operating procedures.
- Personnel shall perform all tasks in accordance with current applicable ES&H guidelines and those specified within the step.
- 1.7 Cover the 3Q60 Coil Assembly with green Herculite (Fermi stock 1740-0100) when not being serviced or assembled. Completed coils are to be stored in the 3Q60 Coil Storage Area.

2.0 Parts Kit List

Attach the completed Parts Kit List for the 3Q60 Coil Assembly/Insulation to this traveler. Ensure that the serial number of this traveler.				
Verify that the Parts Kit received is complete.				
111111111111111111111111111111111111111				
	ν			

FMI 3Q60 Coil Assembly/Insulation

3.0 -	sembly In	

When lifting and or moving coils or coil assemblies always have the four (4) Ty-Raps (Fermi stock 1150-2080 or equivalent) installed at the quarter points of the coil or coil assembly.

Transport two (2) 3Q60. Outer (small) Coil Assemblies (ME-331982) supported on tape wrapped 2 x.4's from the coil staging area on a coil transport cart to the coil insulating area. Visually inspect the coils conductor wrap for damage and ensure the G-10 insulation is between the layers of the coils. Record the serial numbers of the coils below.

	Record t	he: Outer Coil Serial Number:	
	Record t	he Outer Coil Serial Number:	
		Lead Person	Date
X	3.2	Verify that the "OK to Proceed" tags are attached to the coils. this traveler.	
		Lead Person	Date
X	3.3	Transport two (2) 3Q60 Inner (large) Coil Assemblies (ME-33 2 x 4's from the coil staging area on a coil transport cart to the inspect the coils conductor wrap for damage and ensure the G-the coils. Record the serial numbers of the coils below.	e coil insulating area. Visually
	Record	he Inner Coil Serial Number:	
	Record t	he Inner Coil Serial Number:	
		Leâd Person	Date
X	3.4	Verify that the "OK to Proceed" tags are attached to the coils. this traveler.	Remove the tags and attach them to
		Lead Person	Date

FMI 3Q60 Coil Assembly/Insulation

		ne repair, give a detailed description of the repa
	and the repair location for each coil requiri	ng repair below.
	None Required	acceptable for use go to Step 3.7.
	None Required	acceptable for use go to Step 3.7.
	None Required	- -
3.6		

This test is only required if the coils have been in storage for more than 24 hours. If work is continuous no electricals are required, but the visual inspections must be done.

X. 3.7 Perform a Coil Integrity Electrical inspection and record the results below. Compare the results with the post conductor wrap electrical. The coils must be clamped for the following tests.

	Inner Coil Serial	Number				
Electrical Test	Equipment Serial Number	L'imit:	Actual Measurement	Pass	Fail	Out of Tolerance
Resistance		$6.0~\mathrm{m}\Omega$ to $6.8~\mathrm{m}\Omega$				
LS @ 1 KHz		Reference Test Only Not Subject to Limit Values	(The Market State of the Control of t
Q∙@ I KHž		Reference Test Only Not Subject to Limit . Values				
LS @ 100 Hz	a i kalanda meraka samba Sambalan berhala bahar	103 μH to 113 μH				
Q @ 100 Hz	er november (1777) bestellt bengt er samper-factorische Schultung	7.5 to 8.5				
100 Volt Ring		Reference Test Only Not Subject to Limit Values				

Visually inspect the coil for the following, which will include but not be limited to: П All materials must be clean, dry, free from grease, oils, etc. Fail Pass The insulation is free of damage and there is no exposed copper. Pass Fail There is G-10 placed between the layers of the coil along the straight sections. Pass Fail The G-10 is roughened to enhance bonding with the epoxy. Fail Pass The coil serial number is not covered by insulation. Pass Fail

FML	3Q60	Coil	Assem	bly	7	Insu	lation
-----	------	------	-------	-----	---	------	--------

	Inner Coil Serial Number					
Electrical Test	Equipment Serial Number	Limits	Actual Measurement	Päss	Fail	Out of Tolerance
Resistance		6.0 mΩ to 6.8 mΩ			-	
ĽS @ 1 KHz		Reference Test Only Not Subject to Limit Values	!			
Q @ 1 KHz		Reference Test Only Not Subject to Limit Values				100 (100 (100 (100 (100 (100 (100 (100
ĽS @ 100 Hz		103 μH to 113 μH				
Q @ 100 Hz		°7.5, to 8.5°				
100 Volt Ring		Reference Test Only Not Subject to Limit Values				

Visually inspect the coil for the following, which will include but not be limited to: All materials must be clean, dry, free from grease, oils, etc. Pass Fail. The insulation is free of damage and there is no exposed copper. Fail. Pass There is G-10 placed between the layers of the coil along the straight sections. Pass Fail The G-10 is roughened to enhance bonding with the epoxy. Pass Fail The coil serial number is not covered by insulation. Pass Fail

FMI	3060	Coil	Assembly	y/Insulation

	Outer Coil Serial Number						
Electrical Test	Equipment Serial Number	Limit	Actual Measurement	Pass	Fail	Out of Tolerance	
Resistance ³	4	3.3 mΩ(tō) 3.7 mΩ		-			
LS @ 1 KHz		Reference Test Only Not Subject to Limit Values					
Q @ I KHz		Reference Test Only Not Subject to Limit Values					
LS @ 100 Hz		'33 μH to 41 μH					
Q @ 100 Hz		5:0 to 6.0					
100 Volt Ring	·	Reference Test Only Not Subject to Limit Values				ndi opereti granisa Spran ali ali granisa Spran ali ali granisa	
	Visually inspe	ct the coil for the following	g, which will include but r	ot be lim	ited to:		
All mater	ials must be clean, dry	free from grease, oils, etc.	Pass		Fail		
✓ The insula	ation is free of damage	and there is no exposed cop	per. Pass		Fail	0	

Continued On The Next Page

Pass

EMI 3Q60 Coil Assembly/Insulation

The coil serial number is not covered by insulation.

Coil Serial No.

Fail

	Outer Coil Seria	Nümber							7	
Electrical Test	Equipment Serial Number		ñit'	Actu	al Measurem	ent	Pass	Fail	Out of 7	oleranc
Resistance		3.3 mΩ t	o 3.7 mΩ							
LS @ 1 KHz		Reference Not Subject Val	et to Limit	:						
Q @ 1″KHz		Not Subject	Test Only it to Limit ues							
LS @ 100 Hz		33 Jun t	ο 41 μΗ		-					
Q.@ 100 Hz		:5:0 t	ō 6.0			1	_			
100 Volt Ring			Test Only It to Limit ues					4		
	Visually inspe	ct the coil for	the following	g, which	n will include	e,but n	ot be lin	nited to:		
All mater	ials must be clean, dry	free from gro	ease, oils, etc.			Pass		Fail		
The insul	ation is free of damage	and there is n	o exposed cor	pper.		Pass		Fail		
There is C	G-10 placed between th	e layers of the	coil along th	e straig	ht sections.	Pass		Fail	Õ	-
The G-10	is roughened to enhan	ce bonding wi	th the epoxy.		·	Pass		Fail		
The coils	serial number is not cov	vered by insul	ation.			Pass		Fail		
	Inspector		· · · · · · · · · · · · · · · · · · ·			Date		_		
XX.	Verify the electronic next step. Atta									
ID	Coil Serial	Number				Typ				
1 2	-	<u> </u>	Outer Inner		(ME-33198					
3			Outer		(ME-33198					
4					(ME-33198					
	Lead Inspector			 -		Date				
					Date					

Rev. A

4.0 <u>Half Coil Assembly/Conductor Wrap Procedure</u>

Note(s):

When lifting and or moving coils or coil assemblies always have the four (4) Ty-Raps (Fermi stock 1150-2080 or equivalent) installed at the quarter points of the coil or coil assembly.


Ensure the G-10 pieces have been roughed to enhance bonding with the epoxy.

Ensure that the part numbers have been removed. Ensure that the area about to be wrapped and the G-10 is clean, dry, free from grease, oils, etc...

Ensure that the G-10 parts are clean, if not use Isopropyl Alcohol (Fermi stock 1920-0300) and Heavy Disposable Wipers (Fermi stock 1660-2600 or equivalent).

Set the two (2) Inner Coils (ME-331983) on separate wrapping tables. Remove the Ty-Raps from the inner coils and the Kapton tape used to mark the joint locations on the inner coils. Longitudinally position on top of the inner coils G-10 Sheet Insulation (MB-331808) (Qty. 2), one per side of the long straight sections as indicated by MD-331984.

ID	Coil Type	Completed
2	Inner Coil (ME-331983) (9 Turn Large Coil)	
4	Inner Coil (ME-331983) (9 Turn Large Coil)	



FMI 3Q60 Coil Assembly/Insulation

Coil Serial No. _____

When lifting and or moving coils or coil assemblies always have the four (4) Ty-Raps (Fermi stock 1150-2080 or equivalent) installed at the quarter points of the coil or coil assembly.

Exercise extreme caution in the following step to ensure that no damage occurs to the insulation, or leads of the inner and outer coil packages. The leads of both half coil assemblies must exit at the same end of the full coil assembly.

4.2 Using the overhead crane and approved lifting method, centrally position the outer coils on top of the inner coils per MD-331984 (One (1) outer coil to One (1) inner coil), remove the Ty-Raps and Kapton tape used to mark the joint locations on the outer coils. Using c-clamps or other approved clamping methods, clamp the coils into position aligning the inside radii of the coils with each other.


Note(s):

The leads of both half coil assemblies must exit at the same end of the full coil assembly.

Caution:


This operation represents a pinch hazard.'

ID	Coil Type	Completed
1	Outer Coil (ME-331982) (5 Turn Small Coil)	
On Top Of		
2	Inner Coil (ME-331983) (9 Turn Large Coil)	
3	Outer Coil (ME-331982) (5 Turn Small Coil)	
On Top Of	-	
4	Inner Coil (ME-331983) (9 Turn Large Coil)	



FMI 3Q60 Coil Assembly/Insulation

Position six (6) pieces of G-10 (MB-331993) along the steps of the straight sections of the coil and two (2) pieces of G-10 (MB-331994) along the inside straight sections of the coil. Use 1/2" X .007" Fiberglass Adhesive Back Tape (MA-225104) as required to hold the G-10 pieces in place as per MD-331984.



ID	Cöil Type	Operation.	Completed
1 And 2	Half-Coil Assembly (MD-331984) (14 Turn Coil)	G-10 In Place	
3 And 4	Half-Coil Assembly (MD-331984) (14 Turn Coil)	G-10 In Place	

		Technician(s)	Date	
X	4.4	Visually-verify-that step 4.1 through 4.3 with MD-331984.	have been completed and that the coil package	s comply
		Lead Inspector		


 $\mathbf{X}^{\mathbf{x}}\mathbf{X}$

Starting 2 37/64" to 2 13/16" in from the end of the coil, conductor wrap one (1) layer half lapped Fiberglass Tape .007 X 2" (MA-225574) along the coils straight sections only, stopping 2 37/64" to 2 13/16" from the other end of the coil. Remove the clamps and the Fiberglass adhesive back tape as required to wrap the coils:

Note(s):

The Fiberglass tape used to hold the G-10 in place prior to wrapping is to be removed and not wrapped into the coil assembly.

ID,	Coil Type	Operation	Completed
1 And 2	Half-Coil Assembly (MD-331984) (14 Turn Coil)	Insulated	
3 And 4	Half-Coil Assembly (MD-331984) (14 Turn Coil)	Insulated	



FMI 3Q60 Coil Assembly/Insulation	Coil Serial No.

5:0 Full Coil Assembly/Ground Wrap Procedure


Note(s):

Ensure the G-10 pieces have been roughed to enhance bonding with the epoxy:

Ensure that the part numbers have been removed. Ensure that the area about to be wrapped and the G-10 is clean, dry, free from grease, oils, etc...

Ensure that the G-10 parts are clean, if not use Isopropyl Alcohol (Fermi stock 1920-0300) and Heavy Disposable Wipers (Fermi stock 1660-2600 or equivalent).

Using the overhead crane and the appropriate slings, invert one of the half coil assemblies and place it on the wrapping stands. Longitudinally position on top of the coil two (2) pieces of G-10 Sheet Insulation (MB-331987), one per side of the long straight sections as indicated by MD-331966:



Technician(s)

Date


Rev. A

Using the overhead crane and the appropriate slings, position the other half coil assembly (not inverted) on top of the inverted half coil assembly presently on the wrapping stands.

Longitudinally and latitudinally position the two (2) half coil assemblies on top of each other per MD-331966. Then clamp the two (2) half coil assemblies together using c-clamps or other pre-approved clamping methods.

Note(s):

The leads of both half coil assemblies must exit at the same end of the full coil assembly.



Technician(s) Date

First and second layers of ground wrap insulation may be applied simultaneously.


During the application of the ground wrap, it is the responsibility of the technicians wrapping the coil to perform continual inspections of the area being ground wrapped for but not limited to, damaged insulation, dirt, debris, oil, grease, etc...

5.3 Starting 2'37/64" to 2.13/16" from the end of the coil, apply one layer half-lapped 2" wide X .007 thick Fiberglass Tape (MA-225574) to the straight sections of the coil removing the clamps as you wrap, stopping 2 37/64" to 2 13/16" from the other end of the coil. Continue in this fashion until the straight sections of the coil have been completely wrapped.

1st Layer Applied

Starting 2.37/64" to 2.13/16" from the end of the coil, apply one layer half-lapped 2" wide X .007 thick Fiberglass Tape (MA-225574) to the straight sections of the coil; stopping 2.37/64" to 2.13/16" from the other end of the coil. Continue in this fashion until the straight sections of the coil have been completely wrapped.

2nd Layer Applied



Note(s):

Adhesive tape is to be removed during the ground wrapping. Transitions between the Fiber Glass (MA-225574) and the Fiber Glass (MA-225574) must be made so that no area of the conductor is uninsulated, but additional build-up of the conductor is minimized.

_	
Technician(s)	Date

Visually inspect the ground-wrap insulation to ensure uniform application. Perform a visual inspection of the assembly and Electrical inspection, record the results below. The coils are not to be clamped for the following tests.

Inner ID# 2 Coil Serial Number						
Electrical Test	Equipment Serial Number	Eimit;	Actual Measurement	Pass	Fail	Out of Tolerance
Resistance		$6.0 \text{ m}\Omega$ to $6.8 \text{ m}\Omega$				
LS'@1.KHz		Reference Test Only Not Subject to Limit Values	1			e de la companya de
Q @ KHz		Reference Test Only Not Subject to Limit Values				
ĽS;@ [;] 100 Hz		Reference Test Only Not Subject to Limit Values				ger Welden gebruik
Q*@ 100 Hz		Reference Test Only Not Subject to Limit Values				
100 Volt Ring		Reference Test Only Not Subject to Limit Values				Algeria

TO O	uter ID# 1 Coil Se	erial Number				
Electrical Test	Equipment Serial Number	Limit	Actual Measurement	Pass	Fail	Out of Tolerance
Resistânce	-	$3.3 \text{ m}\Omega$ to $3.7 \text{ m}\Omega$				
LS @ 1 KHz		Reference Test Only Not Subject to Limit Values				
Q:@ 1 KHz		Reference Test Only Not Subject to Limit Values				
ES:@ 100 Hz		Reference Test Only Not Subject to Limit Values				
Q @ 100 Hz		Reference Test Only Not Subject to Limit Values				
100 Volt Ring	,	Reference Test Only Not Subject to Limit Values	All of the consequences (1997). When the consequences of the conse			
Hipot Inner Coil to Outer Coil @ 100 Vdc		< 5μΑ				


FM	II 3	Q60	Coil	Assem	bly/	Insul	lation


	nner ID# 4 Coil S	erial Number				
Electrical Test	Equipment Serial Number	Limit	Actual Measurement	Pass	Fāil	[™] Out of Tolerance
Resistance		6.0 mΩ to 6.8 mΩ	,		1	_
LS @ 1 KHz		Reference Test Only Not Subject to Limit Values				
Q@1KHz		Reference Test Only Not Subject to Limit Values				
L'S [@-100,Hz		Reference Test Only Not Subject to Limit Values	<u> </u>			
Q @ 100 Hz		Reference Test Only Not Subject to Limit Values	. •			de la companya de la La companya de la co
100 Volt Ring		Reference Test Only Not Subject to Limit Values	a Shearing are properties.		•	
C	Outer ID# 3 Coil S	eriäl Nümber	·			
Electrical Test	Equipment Serial Number	Limit	Actual Measurement	Pass	Fail	Out of Tolerance
Resistance		3.3/mΩ/to 3.7 mΩ				
LS® 1 KHz		Reference Test Only Not Subject to Limit Values				Scotland Scotland of the control of
Q @ 1 KHz		Reference Test Only Not Subject to Limit Values				
LS @ 100 Hz		Reference Test Only Not Subject to Limit Values		Park Congress		
Q @ 100 Hz		Reference Test Only Not Subject to Limit - Values				erenerakan di Pere Karaman Perengan Karaman di Karaman
100 Volt Ring		Reference Test Only Not Subject to Limit Values				
		< 5μ <u>A</u>				
Hipot Inner Coil to Outer Coil @ 100 Vdc Hipot Inner						<u> </u>

FMI 3Q60 Coil Assembly/Insulation

If so designated by Engineering a specific core i.e.. (a core which exceeds the longest allowable dimension per the core print) maybe used as a Go/Go No gage. If this is the case skip step 5.5 and complete the table provided in step 5.6 on page 21, if not complete the dimensional called out below.

Mechanically inspect the coil using a Vernier Caliper (Starrett Part No. 723 or equivalent) at the indicated locations and record your readings in the table provided.







Left Side

Are Located At The Lead End

		~~~~			
Location	Desired Dimension	Measured Dimension	Pass	Fail	Out Of Tolerance
WL1	2.39" to 2.45"			-	
WL3	2.39" to 2.45"				
W:L5	2.39" to 2.45"				
HL1	3.69" to 3.75"				
HL3	3.69" to 3.75"				
HL5	3.69" to 3.75"				



Use The Measurement Locations Called Out In The Top View Above




NOTE: Locations HL5 And HR6 Are Located At The Lead End

Right Side

1119111						
Location	Desired Dimension	Measured Dimension	Pass	Fail	Out Of Tolerance	
WR2	2:39" to 2.45"					
WR4	2.39" to 2.45"			-		
WR6	2:39" to 2.45"	<del></del>				
HR2	.3.69" to 3.75"				·-	
HR4	3\69" to 3.75"				-	
HR6	,3:69" to 3.75"					

Rev. A

## **Continued From The Previous Page**



Inside Measurements

	Location	Desired Dimension	Measured Dimension	Pass	Fail	Out Of Tolerance
1	WL1 to WR2	2.61" Minimum				
I	WL3 to WR4	2.61" Minimum				
I	WL5 to WR6	2.61" Minimum				
	OL	66.44" Maximum				
L	IL	61.60" Minimum				

5.6 Complete the table below using the Go / No Go-gage indicated by Engineering.

			Go / Go No Gage									
			Core	Serial	Number	Pass	Fail	]				
				<del></del>								
		Inspector				-		Date				
X	5.7	Visually inspect	the coil	for the t	following,	which wi	ll include	but no	t be limi	ted to:		
,	All motariole mu	ust be clean, dry, fi	naa fuam	Branca.	aila ata			Door	$\neg$	er. u		
χ.	An materials int	ist be clean, dry, n	ree from	grease,	ons, etc			Pass	<b>_</b> _	Fail		
1	The insulation is	free of damage ar	d there i	s no exp	osed coppe	er.		Pass		Fail		
7	The coils serial i	numbers are not co	vered by	/ insulat	ion.			Pass		Fail		
		Inspector						Date				

X _* X	5.8	Verify that the recorded results are in compliance with MD-331984/MD-331966 and ES-331810. Remove the temporary identification labels and scribe the coil serial number on to a Tie Wrap (MB-318794) using a Panduit Marking Pen (PFX-0-Black) and attach the tie wrap to the coil assembly at the lead end. Ensure that the coil serial number matches that at the bottom of this traveler.				
		Lead Inspector	Date			
		Crew Chief	Date '			
	5.9	Transport the insulated coil on the coil tra	ansport cart to the coil staging area for further assembly.			
		Technician(s)	<u>Date</u>			

6:0	6:0 Production Complete						
XXX	6.1	all operations have been completed and signe	This shall include a review of all steps to ensure that d off. Ensure that all Discrepancy Reports, rms, Deviation Index and dispositions have been				
		Comments:					
			<u> </u>				
		Process Engineering/Designee	Date				
XXX.	6.2	accurate and complete. This shall include a new been completed and signed off. Ensure that a	embly/Insulation Traveler: (5520-TR-333291) is eview of all steps to ensure that all operations have II Discrepancy Reports, Nonconformance Reports, ispositions have been reviewed by the Responsible wed.				
		Comments:					
		Assembly/Designee	Date				
7.0	Attach	Attach the Process Engineering "OK to Proceed" Tag on the coil.					
		Process Engineering/Designee	Date				
8.0	Procee	ed to the next major assembly operation - 3Q60	Half Magnet Assembly Traveler (5520-TR-333292).				
-							
FMI 3	3060 Coi	l Assembly/Insulation	Coil Serial No				